145.00 mm

CHEFMAN™

INSTRUCTION BOOKLET

CHEFMAN HAND BLENDER	RJ10 *COLOR SERIES*

For your safety and continued enjoyment of this product, always read the instruction manual before using.

HOW TO OPERATE

1. Plug power cord into 120 volt AC outlet.
2. Place blade end of unit directly into bottom of a tall plastic container holding ingredients to be blended.
3. Your blender has 2 speeds (high and low) Press the high (bottom button) or low (top button) for continuous blending. Blending action stops when button is released.
4. **NOTE:** During use, it is normal for a suction to be created at the bottom of the container.
5. For a short burst of blending, quickly push and release the LO or HIGH setting.
6. After Blending, unplug unit.

Caution: Do not use blender in saucepan directly on stovetop. Remove pan from heat before blending. To avoid splatter, never lift blender out of ingredients while motor is on.

CLEANING YOUR HAND BLENDER

1. For easy cleaning, place blade-end of unit under hot, running water immediately after blending is completed.
2. Wipe motor-end of handle with a damp cloth or sponge.
3. The blender-shaft and blade are all dishwasher safe. **Do not put the motor portion in dishwasher**.

- Some foods, e.g. carrots, may discolor the plastic. Rubbing with a cloth dipped in vegetable oil helps remove discoloring..

TIPS

- For thorough blending, add liquid portion of recipe last unless you are blending a powdered mix with a liquid, add the liquid first and then the powder (e.g. water for soup mix).
- Remember: The blender performs its tasks in seconds not minutes. Stop blender and check the consistency before contents become too fine or over blended.
- Do not overtax the blender with extra heavy loads such as stiff dough.
- If blending action in container should stop during processing before mixture is smooth, unplug unit and remove ingredients from blade with rubber spatula. Plug in unit to complete blending.
- It may be necessary to stop blending action and remove blade-end from ingredients and reinsert several times before mixture becomes smooth.
- To make beverages icy cold, add one ice cube at a time (up to 6) to an already blended mixture. Raise and lower blender in a steady motion until ice is crushed.
- **NOTE:** Your blender is not designed to crush larger quantities of ice.

SPLATTER FREE BLENDING

- Avoid lifting unit out of ingredients while motor is on.
- To prevent spillage: Fill a container about two thirds full. Suggested containers: Use beaker for individual servings of drinks and shakes. For larger blending, use mixing bowl or measuring cup with a 2-cup capacity or larger.

CHEFMAN™

210.00 mm

IMPORTANT SAFEGUARDS

1. **READ ALL INSTRUCTIONS**.
2. To protect against fire, electric shock and injury to persons, **DO NOT IMMERSE CORD OR PLUG** in water or other liquids.
3. This appliance should not be used near children.
4. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
5. Avoid contacting moving parts.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance has malfunctioned or has been damaged in any manner. Return the appliance by calling 888-315-8407 for examination, repair or replacement.
7. The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock or injury.
8. Do not use outdoors.
9. Do not let power cord hang over edge of table or counter, or touch hot surfaces.
10. Never exceed the maximum operating time outlined in this manual.
11. Always unplug the unit when finished using.
12. Do not use appliance other than its intended use.
13. Unplug before changing or adding parts.
14. **Caution: Do not operate appliance for more than 30 seconds at a time.** Pause for four (4) minutes before resuming use of your hand blender.
15. When mixing liquids, especially hot liquids, use a tall container or make small quantities at a time to reduce spillage. **Never blend hot oil or fat.**
16. Keeps hands and utensils out of the container while blending to prevent the possibility of severe injury to persons or damage to the unit. A scraper may be used but must be used only when the unit is not running
17. **Blades are sharp. Handle carefully**
18. Keep hands, hair, clothing, as well as spatulas and other utensils away from beaters during operation to reduce the risk of injury to persons, and/or damage to the mixer
19. Keep hands and utensils away from the cutting blade while blending food to reduce the risk of severe injury to persons.

WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, ONLY AUTHORIZED PERSONNEL SHOULD DO REPAIRS.

SAVE THESE INSTRUCTIONS

FOR HOUSEHOLD USE ONLY

SPECIAL CORD SET INSTRUCTIONS

This appliance is for **HOUSEHOLD USE ONLY**. No use-serviceable parts inside. Do not attempt to service this product. A short power-supply cord is provided to reduce the hazards resulting from entanglement or tripping over a longer cord. An extension cord may be used with care; however, the marked electrical rating should be at least as great as the electrical rating of the appliance. The extension cord should not be allowed to drape over the counter or tabletop whether children can pull it on or tripped over.

NOTICE: POLARIZED PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way. If the plug fits loosely into the AC outlet, or if the AC outlet feels warm do not use that outlet.

IMPORTANT

With heavy mixtures, do not use your hand blender for longer than 30 seconds in any four minute period - it will overheat

OPERATING INSTRUCTIONS

Congratulations on buying your new Chefman Hand Blender.

BEFORE FIRST USE

Remove all packaging materials and any promotional labels or stickers from your hand blender. You may want to keep the box and packing materials for use at a later date.

BEFORE PLUGGING IN FOR THE FIRST TIME

Make sure your electricity supply is the same as the one shown on the power handle

GET TO KNOW YOUR HAND BLENDER

A - SPEED BUTTONS AND CONTROLS

B - POWER HANDLE AND SPEED CONTROLS

C - BLENDER SHAFT (REMOVABLE)